

**Table des matières**

<b>Gen8 - upgrade bios &amp; ILO</b> .....	3
Fichiers .....	3



## Gen8 - upgrade bios & ILO

### Fichiers

- [bios\\_SP99233.exe](#) ⇒ extraire le fichier `SP99233.exe\ROMPaq Flat Files\CPQJ0613.436`
- [ilo\\_cp046021.exe](#) ⇒ extraire le fichier `cp046021\ilo4_277.bin`
- Flasher via l'ILO :

The screenshot shows the ILO 4 management interface. The left sidebar contains navigation options like Overview, System Information, ILO Event Log, Integrated Management Log, Active Health System Log, Diagnostics, Location Discovery Services, Insight Agent, ILO Federation, Remote Console, Virtual Media, Power Management, Network, Remote Support, Administration, Firmware, Licensing, User Administration, Access Settings, Security, Management, Key Manager, and ILO Federation. The main content area is titled 'Firmware Update' and includes a 'Firmware Information' table with columns for Type, Date, and Version. The current ILO version is 2.77, dated Dec 07, 2020. Below the table, there are instructions on how to obtain the firmware image and a section for 'Server Firmware' listing updateable components like HPE System ROM, System Programmable Logic Device, and SLOX Chassis Firmware. At the bottom, there is a 'Local File' section with an 'Upload' button.

From: <https://unix.ndlp.info/> - Where there is a shell, there is a way

Permanent link: [https://unix.ndlp.info/doku.php/blog:gen8\\_-\\_upgrade\\_bios\\_ilo?rev=1614848008](https://unix.ndlp.info/doku.php/blog:gen8_-_upgrade_bios_ilo?rev=1614848008)

Last update: 2021/03/04 08:53