

**Table des matières**

remplacement power ..... 3



## replacement power

```
BWR-01-sc0:sms-svc:3> showenvironment -p powers
```

POWER	UNIT	AC0	AC1	DC0	DC1	FAN0	FAN1
A211 at PS0	OK	OK	OK	ON	ON	OK	OK
A211 at PS1	OK	OK	OK	ON	ON	OK	OK
A211 at PS2	FAIL	FAIL	FAIL	OFF	OFF	OK	OK
A211 at PS3	OK	FAIL	OK	ON	ON	OK	OK
A211 at PS4	OK	FAIL	OK	ON	ON	OK	OK
A211 at PS5	OK	FAIL	OK	ON	ON	OK	OK

- In case of reset of a domain 25k: change post level to 7 in order to avoid 2h of post check

```
cd $SMSETC  
profile
```

From:  
<https://unix.ndlp.info/> - **Where there is a shell, there is a way**

Permanent link:  
[https://unix.ndlp.info/doku.php/informatique:nix:solaris:solaris\\_25k](https://unix.ndlp.info/doku.php/informatique:nix:solaris:solaris_25k)

Last update: **2015/03/31 07:57**