

Table des matières

remplacement power 3

remplacement power

```
BWR-01-sc0:sms-svc:3> showenvironment -p powers

POWER          UNIT    AC0    AC1    DC0    DC1    FAN0    FAN1
-----
A211 at PS0    OK      OK     OK     ON     ON     OK     OK
A211 at PS1    OK      OK     OK     ON     ON     OK     OK
A211 at PS2    FAIL    FAIL    FAIL    OFF    OFF    OK     OK
A211 at PS3    OK      FAIL    OK     ON     ON     OK     OK
A211 at PS4    OK      FAIL    OK     ON     ON     OK     OK
A211 at PS5    OK      FAIL    OK     ON     ON     OK     OK
```

- In case of reset of a domain 25k: change post level to 7 in order to avoid 2h of post check

```
cd $SMSETC
profile
```

From:
<https://unix.ndlp.info/> - **Where there is a shell, there is a way**

Permanent link:
https://unix.ndlp.info/doku.php/informatique:nix:solaris:solaris_25k

Last update: **2015/03/31 09:57**